


Additional function


Manual Temperature Preselection

On request, we provide this additional function to all temperature control units, preferably for the models TT-288 and TT-388.



Operating principle

Switch position «0»; It controls to the set temperature on the controller. The temperature preselection can be used to pre-set 5 different temperatures. By changing the switch position, the pre-set temperature will be automatically set on the controller.



The temperature settings can be adjusted on the relay in the electrical cabinet. On the relay are 5 potentiometers. To adjust the temperature, the switch must be in the corresponding position. Turning clockwise will set the temperature up, turning counter-clockwise will set the temperature down. The pre-set temperature will be shown at the controller. The information sign should be indicated according to the set temperatures.